

# Hemmer and Lace Foot

For sewing lace, trim and tapes onto hems. The bottom edge of the fabrics is simultaneously neatened with a narrow or wide coverstitch, creating a flat joining seam.

Article number: 502040 60 31

## Instruction

1. Set machine for "wide or narrow Coverstitch".
2. Raise the presser foot and snap on "Hemmer and lace foot".
3. Insert lace into the right guide and slide it 1" (25mm) beyond the needles.
4. Fold the fabric under  $\frac{1}{4}$ " (6mm). Insert the fabric into left guide with the folded side down. Slide the fabric under the foot to the needles.
5. Lower the presser foot and sew.

