



Straight Stitch Plate



1



2



Information

Purpose

- For straight stitch and free-motion sewing as well as for quilting with rulers.
- For embroidering and CutWork projects.

For Your Safety

Before using this accessory, please read this instruction manual as well as the instruction manual of your machine carefully.

Application

Changing the Stitch Plate

- > Switch off the machine and disconnect it from the power supply.
- > Remove the needle.
- > Remove the presser foot.
- > Lower the feed dog and remove the bobbin cover.
- > Remove the screws of the stitch plate with the screwdriver. (Fig. 1)
- > Remove the stitch plate.
- > Insert the straight stitch plate and tighten the screws with the screwdriver. (Fig. 2)