

BABY LOCK SEWING ACCESSORIES

Embroidery Foot

(BLR-EF)


Instructions

This Embroidery Foot was created as a computerized machine embroidery foot replacement. If you have misplaced the foot included with your Ellure Plus (BLR2), Ellure (BLR), Emore (BLMR) or Sofia (BL137A), don't worry, this is the foot you need!

INSTRUCTIONS:


1. Attach the embroidery foot "Q" when embroidering. Have the included embroidery foot "Q" and a screwdriver ready.

Note: Always use the embroidery foot "Q" when embroidering. If the wrong presser foot is used, the needle may hit the presser foot and bend or break.



- ① Embroidery foot bar
- ② Caught by the presser foot holder screw

2. Press ① (Needle position button) once or twice to raise the needle.




- ① Needle position button

3. **Note:** The needle is correctly raised when the mark on the handwheel is at the top. Check the handwheel mark to make sure it is at the top position.


4. Turn off the sewing machine.

5. Raise the presser foot lever.



- ① Presser foot lever

6. Press and hold the black button on the back of the presser foot holder to detach the presser foot. The presser foot holder releases the presser foot.



- ① Black button
- ② Presser foot holder



FOR THE LOVE OF SEWING