

## ALL ABOUT the standard presser foot

The standard foot is used for most traditional sewing such as seams or topstitching. The foot holds the fabric firmly in front of the needle but a clear view of your stitching is possible because of the clear plastic centerpiece.

There are marks on the the foot to help in guiding your fabric as you stitch. These marks also indicate the center (1), far left (2) and far right (3) needle positions.

The standard presser foot was designed to accommodate straight or long, zigzag stitching. The cutout (4) area on the bottom of the foot is not deep enough for any satin stitching without the possibility of bunching of stitches.

### seams

For a typical 5/8" seam using the left needle position, place the fabric under the foot and align the fabric with the marking on the needle plate.



If using the center needle position, align the fabric edge slightly to the left of the 2mm marking on the needle plate.

