

# Hemmer Foot

The hemmer foot quickly and easily sews even seams with a depth of 2.5 cm. A narrow or wide coverstitch can be used to neaten the cut edge.

Article number: 502040 60 29

## Instruction

1. Set machine for "Coverstich".
2. Raise the presser foot and snap on "Hemmer foot".
3. Insert fabric from the left side until the edge of fabric lays against the guide.
4. Lower presser foot and sew, 1" (25mm) of hem is produced.
5. Note: when sewing in a circle, at seam end sew about 1" (25mm) over the first stitches.

