

Standard presser foot

The standard presser foot is a loyal companion for everyday overlocking and coverstitch projects. It is perfect for tidying up individual layers of fabric and for creating flat seams and rolled seams. The fabric edge is cut back, sewn and finished off in one step. The flat sole ensures that the fabric is in constant contact with the feeder guide, providing a smooth sewing experience.

Article number: 502040 60 24

Instruction

1. Set machine for a Coverstitch or Chain Stitch.
2. Raise the presser foot and change to "Standard presser foot".
3. Note: this foot can be used to sew along the fabric hem or decorative in the middle of fabric.
4. Place fabric under the foot and lower it.
5. Sew, guiding the fabric as needed.
6. This see-through foot lets you see stitches under the foot as you sew.
7. It is especially useful to match up the end of a hem seam with its start for a beautiful finish.

