

# Standard presser foot overlock

#L10



1



## Information

### Purpose

- For all overlock stitches.
- For general sewing projects.
- To sew on tape up to a width of 12 mm.

### For your safety

Before using this accessory, please read the instruction manual at hand as well as the instruction manual of your machine carefully.

### Markings and guides

- A Cutting line at cutting width 6
- B Right needle RN
- C Left needle LN
- D 1 cm distance to the cutting line A at cutting width 6
- E Adjustable tape guide

2



## Operation

### Sewing a tape

- > Raise the needles and the presser foot.
- > Swing out the presser foot.
- > Place the tape under the presser foot and insert it into the tape guide from the right. (fig. 2)
- > Swing the presser in and lower it.
- > To fix the tape, sew a few stitches on the tape.
- > Loosen the screw at the ribbon guide lightly.
- > Adjust the tape guide suitable for the width of the tape so that at least one needle can stitch the tape.
- > Tighten the screw at the tape guide again.
- > Lift the presser foot tip and place the fabric.
- > Sew the tape. (fig. 3)

3

