

Clear Overlock Foot

#L27



Information

Purpose

- For all overlock stitches.
- For general and decorative sewing.
- For precise stitches thanks to a good view of the needle area.
- For sewing on fine braid up to 9 mm in width.

For your safety

Before using this accessory, please read the instruction manual at hand as well as the instruction manual of your machine carefully.

Markings

- A Tape guide
- B Cutting line at cutting width 6
- C Right needle RN
- D Left needle LN
- E 1 cm distance to the cutting line A at cutting width 6

Application

Sewing a tape

- > Raise the needles and the presser foot.
- > Swing the presser foot out. Thread the tape into the tape guide from above and lay it under the presser foot towards the back. (Fig. 2)
- > Swing the presser foot in.
- > Lower the presser foot.
- > To fix the tape in place, sew a few stitches on the tape.
- > Lift the presser foot tip and place the fabric.
- > Sew the tape. Guide the tape so that at least one needle can pierce the tape. (Fig. 3)

