BABY LOCK SERGER ACCESSORIES

Pintuck Foot

(BLE8-PTF)

Instructions


Use this foot on your serger to add beautiful texture to a classic heirloom or everyday garment. The five grooves on this foot allow for perfect spacing with professional results. Achieve precise pintucking when making corded and hollow tucks as well as parallel and curved forms.


- 1. Change to sewing table from knife cover.
- 2. Set needles C2 and C3.
- 3. Open the side cover, place one of the guides on the needle plate and close the side cover.
 - To make raised but non-corded pintucks, use guide A.
 - To insert cording into the pintuck, use guide B and slide the cord into the guide.
- 4. Place the fabric under the presser foot and sew it.

MACHINE SETTINGS

Needle :	C2 and C3
Upper knife :	Disengaged "LOCKED"
Stitch type :	Narrow Cover Stitch
Stitch width :	"M"
Stitch length :	3mm
Differential feed :	N (N-0.6 for finer fabrics)









800-422-2952

www.babylock.com