

# Blindhem Foot

(BLE8-BLHF)

## Instructions

Looking for a quick, easy way to make your hems invisible? This foot was designed specifically for easily stitching a blindhem on the serger. You can also use this foot for quick stitching along fabric edges.

### MACHINE SETTINGS

|                    |                             |
|--------------------|-----------------------------|
| Needle:            | 02                          |
| Upper knife:       | Engaged "UNLOCKED"          |
| Stitch type:       | 2-Thread Narrow Hem         |
| Stitch selector:   | B                           |
| Stitch width:      | 5.0 mm                      |
| Stitch length:     | 3.5                         |
| Differential feed: | N (N-0.6 for finer fabrics) |

### INSTRUCTIONS:

1. For hemming, fold fabric as shown in diagram.
2. Place garment with wrong side up under the presser foot. Before you begin serging, check the needle dropping position. The needle should just catch the fold of the fabric.
3. Once the needle dropping position has been determined, set the adjustable guide on the foot to the fold edge of the fabric. Move the adjustable guide by loosening the screw on top of the foot, adjusting the plate right or left and retightening the screw.

